	🗞 cymatic audic
	uTrackхза
© ©	32-track recorder player REC status HDD format Image: Statu

User Manual uTrack-X32 Jan 2016



Table of Contents

1.	SAFE	ETY PRECAUTIONS	3
2.	USA	GE PRECAUTIONS	4
3.	LIMI	ED WARRANTY	4
4.	INTR	ODUCTION	5
4	.1. Fe	eatures	5
5.	INST	ALLATION PROCEDURE	6
6.	CON	NECTORS and CONTROLS	7
6	.1. C	onnections	7
6	.2. U	ser Interface	7
7.	REC	ORDING	8
7	.1. Fo	ormatting: Preparing the Hard Drive for Recording	8
7	.2. U	SB Hard Drives vs. USB Flash Drives	8
7	.3. M	aking a Recording	Э
8.	PLAY	/BACK (Sound Check)1	0
9.	uToo	l1	0
10.	uRen	note1	0
11.	uTrac	x-X32 as a COMPUTER AUDIO INTERFACE1	1
1	1.1. O	S X1	1
	11.1.	1. Minimum System Requirements1	1
	11.1.	2. Driver Installation	1
1	1.2. iC)S1	2
	11.2.	1. Minimum System Requirements1	2
	11.2.	2. Driver Installation	2
1	1.3. M	icrosoft Windows1	3
	11.3.	1. Minimum System Requirements1	3
	11.3.	2. WDM and ASIO Driver Installation1	3
	11.3.	3. uTrack-X32 Control Panel for Windows1	3
12.	LEGA	AL DISCLAIMER	9



1. SAFETY PRECAUTIONS

Installation

- Be sure to disconnect your console from power when installing your uTrack-X32.
- Carefully insert the uTrack-X32 card into the side guides of the console's expansion slot.
- Push the uTrack-X32 card softly into the expansion slot until it is fully contacting the internal connector of your console.

Environment

To prevent the risk of fire, electric shock or malfunction, avoid using your uTrack-X32 in environments where it will be exposed to:

- Extreme temperatures
- Heat sources
- Excessive humidity or moisture
- Excessive dust or sand
- Excessive vibration or shock

Handling

Do not touch the electronic parts or traces on your uTrack-X32 card. Hold the module only on the orange rear panel or on the pull handles

Alterations

Do not attempt to modify the product in any way. Doing so will void the warranty. There are no serviceable parts on this card.



2. USAGE PRECAUTIONS

Electrical interference

For safety considerations, the uTrack-X32 has been designed to provide maximum protection against the emission of electromagnetic radiation from inside the device, and protection from external interference. However, equipment that is very susceptible to interference or that emits powerful electromagnetic waves should not be placed near the uTrack-X32, as the possibility of interference cannot be ruled out entirely. With any type of digital control device, the uTrack-X32 included, electromagnetic interference can cause malfunctioning and can corrupt or destroy data. Care should be taken to minimize the risk of damage.

Cleaning

Use a soft, dry cloth to clean the rear panel of your uTrack-X32 card. If necessary, slightly moisten the cloth. Do not use abrasive cleanser, wax, or solvents (such as paint thinner or cleaning alcohol), since these may dull the finish or damage the surface.

3. LIMITED WARRANTY

For the applicable warranty terms and conditions and additional information on Cymatic Audio's Limited Warranty, please see complete details online at <u>www.cymaticaudio.com/warranty</u>

CERTIFICATIONS



This product complies with the European Union Council Directives and Standards relating to Directive 2004/108/EC for Electromagnetic compatibility (EMC) and Low Voltage Directive 2006/95/EC

This product is compliant with the EU Directive 2011/65/EU for the Restriction of the use of Certain Hazardous Substances in Electrical and Electronic Equipment. No lead (Pb), cadmium (Cd), mercury (Hg), hexavalent chromium (Cr+6), PBB or PBDE is intentionally added to this device. Any traces of impurities of these substances contained in the parts are below the RoHS specified threshold levels.



This equipment has been tested and found to comply with the requirements of 47 CFR of PART 15 limit for radiation and conduction emission relating to FCC rules Part 15B: 2010.



A NOTE ABOUT DISPOSAL:

This product must be disposed in accordance with the local recycling regulations. The crossed out wheeled bin symbol informs you that the product should not be disposed of along with municipal waste and invites you to use the appropriate separate take-back systems licensed for the recycling of electrical and electronic equipment (EEE).



4. INTRODUCTION

The uTrack-X32 is a 32-track recorder/player/audio interface. It is an option card for the X32/M32 range of consoles (or any other X series console that contains the 32x32 option card slot).

The card can be used for:

- Live 32-channel multitrack recording
- Virtual sound check
- Playback using predefined playlists

4.1. Features

- Records 32 separate audio channels at 24-bit resolution from the X32 series console to a standard USB hard drive (FAT-32 format)
- Plays back 32 separate audio channels from a standard USB hard drive (FAT-32 format) into the X32 console (uRemote software and network connection required)
- Streams 32-inputs and 32-outputs through USB to/from the X32 console on Windows, OSX, iOS phones and iOS tablets
- Direct digital pathway from console, no additional A/D or D/A conversion
- "One click recording" directly from the card
- Recording time limited only by the size of the attached hard disk
- Can be controlled remotely using the uRemote software (available free of charge for Windows, OS X, iOS and Android) for additional functions:
 - Detailed status information and configuration
 - o Playback, including playback head positioning and playback loops
 - o Load and playback predefined Playlists
 - o Marker creation during recording
 - Marker selection during playback
 - o Browsing and selection from the hard disk
- Firmware Update using network connection or directly using the USB drive. Please refer to the firmware update guide for uTrack-X32 from www.cymaticaudio.com/downloads



5. INSTALLATION PROCEDURE

Unplug the power cable before installing the uTrack-X32 option card.

The installation procedure is identical to the procedure for any other expansion card for your X32 console. Please read the installation manual of your X32 console and of one of its expansion cards carefully.

Open the 2 screws of the expansion card slot and remove the card:



Align uTrack-X32 option card with the card guides, then push it all the way into the internal connector socket:



Tighten the 2 screws again. Do not use too much force when tightening, in order to prevent stripping the screws:



User Manual uTrack-X32 Jan 2016



6. CONNECTORS and CONTROLS

6.1. Connections



HDD

Connect your USB hard disk to this connector.

USB Interface

Connect to a USB port on your OSX / Windows computer to use your uTrack-X32 card as a 32-input, 32-output audio interface. This interface is not available when a USB hard disk is connected to the HDD port

Network

Connect this port to your local area network. You can then use the uRemote software (Windows / OSX / iOS / Android) to remotely control all features of your uTrack-X32 option card.

6.2. User Interface

REC button

Push the REC button to start a new recording. Long-press the REC button to stop recording. This button turns red when recording is active.

Note: Pushing the record button while a recording is ongoing, starts a new recording take, without losing any data.

Format button

Push the FORMAT button once; the Status LED will start blinking yellow. Press the FORMAT button again to format the connected hard disk.



NOTE: All data will be lost when a drive is formatted.

Status LED

This multi-color LED indicates USB drive status and activity:

Color	State	Description	
Green	On	The USB drive is ready to record	
Green	Blinking	The card is playing back audio from the hard disk	
Yellow	On	The USB drive is ready, but remaining available space is less than 3 hours.	
Yellow	Blinking	The card is waiting for confirmation from the user to start formatting	
Yellow	Slow Blinking	USB drive is being mounted.	
Red	On	Less than 30 minute of recording time is left on the attached drive.	
Red	Blinking	The USB drive is not formatted correctly and is not ready to record	



7. RECORDING

7.1. Formatting: Preparing the Hard Drive for Recording

The uTrack-X32 records on hard drives, which must be formatted in the FAT32 format.

In order to ensure that the hard disk is optimally formatted for audio recording, we recommend that you format it using the card's Format button.

Formatting the hard disk is only possible when the card is idle, i.e., no recording or playback is taking place.

- Press the FORMAT button using a thin pointed object; the Status LED will start blinking yellow.
- Press the FORMAT button again to start formatting the hard disk. The Status LED starts blinking faster. Note: if you do not press the button the second time within 10 seconds, the card will return to the idle state.
- After formatting is complete, the Status LED turns solid green or yellow. This indicates that the drive is
 properly formatted and ready to record.

7.2. USB Hard Drives vs. USB Flash Drives

The uTrack-X32 option card requires certain performance from the USB storage device to operate properly. Current storage devices can be categorized in two general groups: hard drives and flash memory devices.

It is recommended to perform a test recording of the same length of your planned recording, using the same drive you will use at the event.

USB Hard Drives

A USB hard drive stores data on spinning magnetic disks. This is the recommended type of USB media to use with the uTrack-X32, because it has reliable and constant read/write speeds.

USB Flash Memory Devices

A USB Flash Memory Device uses flash memory. Small, cheap flash devices are generally not adequate for use with the uTrack-X32, since they require occasional pauses in data writing. This is problematic for a device that needs to write a constant data stream: a pause in data writing may cause dropouts in your recording.

Some flash devices will perform correctly. Generally, it is easier to find a usable flash device within the ones marketed as SSDs (Solid-state Drives).

Mounting the Hard Drive

The uTrack-X32 mounts the attached drive's file system automatically after a USB drive is connected. The card optimizes disk writes at startup to avoid problems with fragmented file systems. With large drives it may take up to a minute to complete the optimization process. After inserting the drive, the card blinks both the recording LED and the status LED once. When mounting the drive, the status LED blinks very slowly.



7.3. Making a Recording

New recordings can be initiated using the Record button on the uTrack-X32 card or using the uRemote software.

- Use the user interface of the X32 console to route the desired signals to the external card. Please consult your X32 user's manual for instructions on routing signals.
- Press the uTrack-X32's Record button to initiate a recording. The recording button's LED will turn to solid red, indicating a recording is now taking place. All recordings are placed into the attached drive's "MultiTrack" folder.
- To stop the recording, press and hold the Record button for a few seconds. The recording will stop, and the red LED will turn off.
- To start a new gapless take, click the Record button shortly during recording.

Pre-Recording Function

The uTrack-X32 card implements a "pre-recording" function. When idle, the card is always recording audio into a temporary buffer.

When the record button is pressed, the take contains audio from a few seconds before the record button is pressed.

This insures you do not miss the first few moments of a recording, even if you are caught by surprise!



8. PLAYBACK (Sound Check)

uTrack-X32 card can be used for playing back multichannel content from the sound console. Virtual sound check can be performed using previously recorded content. It is also useful for expanding live performance with individual prerecorded tracks. Any playback feature is only accessible using the uRemote application. The card provides two modes for playback:

Playlist Mode:

A set of songs can be placed in a specific order inside a playlist file. Each song can be started with different delay options. A playlist for the uTrack-X32 can be created using the uTool application.



Note: When a playlist is loaded, the currently available song is pre-loaded. This means that as soon as the play button is pressed, the song starts playing without any delay

Note: It is possible to playback songs gaplessly inside a playlist. Subsequent songs should have the same channel count, sample rate and bit depth for a gapless playback.

Folder Mode:

The songs in a particular folder are played back depending on the folder mode. The various options to playback the songs inside a folder are: Single, Continuous, Repeat One, Repeat All and Shuffle.

9. uTool

The uTrack-X32 records its multitrack audio to a multi-channel wave file.

In order to easily exchange data with standard computer software, Cymatic Audio offers the free uTool application to convert between uTrack multichannel wave files and separate mono wave files.

For more information please refer to the uTool user's manual, available at www.cymaticaudio.com/downloads

10. uRemote

The uRemote software can be used to remotely control the uTrack-X32 card. It can be downloaded for free from www.cymaticaudio.com/downloads.

Please refer to the uRemote user's manual for more information on uRemote's operation, and how to set up a network with uRemote and the uTrack-X32 card.



11. uTrack-X32 as a COMPUTER AUDIO INTERFACE

Make sure that no hard disk is connected to the uTrack-X32's HDD port. The hard disk mode takes precedence, and audio interface mode is deactivated when a drive is connected.

Use the user interface of the X32 series to route the desired signals to the external card. Please consult your console's user's manual for instructions on routing signals.

11.1. OS X

11.1.1. Minimum System Requirements

Operating Systems:

• Mac OS-X® 10.8 or higher

Hardware:

- Any Mac hardware compatible with OS X 10.8 or higher
- 512 MB Ram (1GB or more recommended)
- One available USB 2.0 compatible port



NOTE: The speed of your processor, amount of RAM, and capacity, size, and speed of your hard drives will greatly affect the overall performance of your recording system.

A faster processor and more RAM can reduce signal latency (delay) and improve overall performance.

11.1.2. Driver Installation

No driver installation is necessary for OS X computers. Simply connect the to your Mac® by connecting the supplied USB cable to the uTrack-X32's USB connector on the rear panel, and an available USB port on your Mac.

The device will now be selectable in the "Audio MIDI Setup" application, which can be found in the Applications/Utilities folder.



11.2. iOS

11.2.1. Minimum System Requirements

Operating Systems:

• iOS® 5 or higher

Hardware:

- iPad® 2 or newer
- Apple® iPad Camera Connection Kit (for iPads with 30-pin connector)
- Apple® Lightning to USB Camera Adapter (for iPads with Lightning connector)

11.2.2. Driver Installation

There is no driver installation for the iPad® necessary. Simply connect the uTrack-X32 to your iPad® by connecting a USB cable to the uTrack-X32 USB connector on the rear panel, and the iPad® using the appropriate Apple USB adapter.

The uTrack-X32 can now be used as a 32-input, 32-output audio interface with the iPad® and appropriate multichannel iOS recording software.



11.3. Microsoft Windows

11.3.1. Minimum System Requirements

Operating Systems (32 or 64 bit):

• Windows 7, Windows 8, Windows 10

Hardware:

- Pentium® IV 1.2 GHz or better
- 512 MB Ram (1GB or more recommended)
- One available USB2.0 compatible port on PC



NOTE: The speed of your computer's processor, amount of RAM, and the capacity, size, and speed of your hard drives will greatly affect the overall performance of your recording system. A faster processor and more RAM can reduce signal latency (delay) and improve overall performance.

11.3.2. WDM and ASIO Driver Installation

Before connecting the uTrack-X32 to your computer, please download the driver package from www.cymaticaudio.com/downloads.

After the download has finished, double click the downloaded file to being the installation and follow the on-screen instructions. (It is strongly recommended that you exit all other programs before running the driver installation program)

When prompted by the installation program, connect the uTrack-X32 to your PC by connecting the supplied USB cable to the uTrack-X32's USB connector on the rear panel and an available USB port on your PC.

11.3.3. uTrack-X32 Control Panel for Windows

The uTrack-X32 driver installation program will automatically install the uTrack-X32 Control panel on your PC.

You can launch it by clicking on the uTrack-X32 icon that will be present in the Windows task bar, or by locating the program's entry in the Windows start menu. The control panel contains for the following settings, organized by the following sections:

🎲 cymatic audio



Devices

e Info			
	Device name	Serial number	
Output Channels Synchronisation Settings	uTrack-X32	0x0015110047000000	Dow
	Edit Device Name		Apply

Device Name: The device name column shows the uTrack-X32 that is currently connected to your computer



Input Channels

	1			
	Device name	Channel name	ASIO display name	*
Input Channels	uTrack-X32	In 1	In 1	
Sunchronisation	uTrack-X32	In 2	In 2	
Settings	uTrack-X32	In 3	In 3	=
, sounde	uTrack-X32	In 4	In 4	
	uTrack-X32	In 5	In 5	
	uTrack-X32	In 6	In 6	1.58
	uTrack-X32	In 7	In 7	
	uTrack-X32	In 8	In 8	
	uTrack-X32	In 9	In 9	
	uTrack-X32	In 10	In 10	
	uTrack-X32	In 11	In 11	
	uTrack-X32	In 12	In 12	
	uTrack-X32	In 13	In 13	
	uTrack-X32	In 14	In 14	
	uTrack-X32	In 15	In 15	
	۲ (III)			•
		Edit Channel Nam	ie Include device name ASIO display name	e in

The input channels section allows you apply custom names to each of the 32 input channels on your uTrack-X32 card. This can be very useful since it allows you to view these custom names from within your DAW software.

To rename an input channel:

- Click on the channel you wish to rename
- Click on the "Edit Channel Name" button, then type your desired custom channel name
- The custom name you have typed will now display in the "ASIO Display Name" column on the right

Click on the "Include Device Name in ASIO Display Name" if you want the list of inputs in your DAW to show "uTrack-X32" at the beginning of the custom name.



Output Channels

	1. 48			
	Device name	Channel name	ASIO display name	*
Input Channels Output Channels	uTrack-X32	Out 1	Out 1	
Supplication	uTrack-X32	Out 2	Out 2	
Settings	uTrack-X32	Out 3	Out 3	=
, counigo	uTrack-X32	Out 4	Out 4	
	uTrack-X32	Out 5	Out 5	
	uTrack-X32	Out 6	Out 6	- (2)
	uTrack-X32	Out 7	Out 7	
	uTrack-X32	Out 8	Out 8	
	uTrack-X32	Out 9	Out 9	
	uTrack-X32	Out 10	Out 10	
	uTrack-X32	Out 11	Out 11	
	uTrack-X32	Out 12	Out 12	
	uTrack-X32	Out 13	Out 13	
	uTrack-X32	Out 14	Out 14	
	uTrack-X32	Out 15	Out 15	-
	۲ III III III III III III III III III I			Þ
		Edit Channel Nam	e Include device name ASIO display name	ein

The output channels section allows you apply custom names to each of the 32 output channels on your uTrack-X32 card. This can be very useful since it allows you to view these custom names from within your DAW software.

To rename an output channel:

- Click on the channel you wish to rename
- Click on the "Edit Channel Name" button, then type your desired custom channel name
- The custom name you have typed will now display in the "ASIO Display Name" column on the right

Click on the "Include Device Name in ASIO Display Name" if you want the list of outputs in your DAW to show "uTrack-X32" at the beginning of the custom name.



Synchronization

2 unack-AS2 USB COnu	or Panel	(<u></u>
File Info	Sampling Rate Selection Mode Automatic Mode	
Settings	Sampling Rate	~
	Clock Source	*
		1 Deviso(c) second ad

The synchronization tab displays the sampling rate that is used by the uTrack-X32. It will automatically be set to match the sampling rate currently used by your X32/M32 console.

Make sure that the sampling rate for your DAW session is set to the same sampling that you see on this tab.



Settings

le Info		
Devices Unput Channels Untput Channels Synchronisation Settings	Isochronous Streaming Stream buffer depth: Minimum latency	
	Audio Buffers ASIO buffer depth: 256 samples	
	ASIO Statistics Drop outs detected: 0	
ettinas		1 Device(s) connected.

Stream Buffer Depth: Use this control to set the overall amount of latency you wish to work with.

- Select "minimum latency" when recording
- Select a higher amount of latency when mixing

ASIO Buffer Depth: Adjust this setting to configure the size of the ASIO buffer, measured in samples.

When using an older, slower computer, you may need to set your latency value to a higher amount. This will reduce the overhead to the computer's CPU and allow your DAW session to run more smoothly, but will result in a higher amount of delay between the original incoming audio signal, and the DAW software'

When using a newer, faster computer, the buffer depth can be set to a lower amount, and latency will be minimized.

ASIO Statistics: This display field indicates how many "drop-outs" have occurred, if any, with the currently selected buffer settings.

Dropouts indicate that your computer's CPU cannot keep up with the demand that is placed on it by the current buffer depth. If any dropouts occur, increase the size of the buffer depth and / or change the streaming mode until no more dropouts are reported.

File Menu: Click on the file menu if you wish to close the uTrack-X32 control panel.

Info Menu: Click on the file menu if you wish to close the uTrack-X32 control panel.



12. LEGAL DISCLAIMER

Technical specifications and appearance are subject to change without notice and accuracy is not guaranteed. Cymatic Audio accepts no liability for any loss which may be suffered by any person who relies either wholly or in part upon any description, photograph or statement contained herein. Colors and specifications may vary from the actual product.

Cymatic Audio products are sold through resellers only. Fulfillers and resellers are not agents of Cymatic Audio and have absolutely no authority to bind Cymatic Audio by any express or implied undertaking or representation.

Apple Macintosh is a trademark of Apple Inc., registered in the U.S. and other countries. Windows is a registered trademark of Microsoft Corporation in the United States and other countries. ASIO is a registered trademark of Steinberg Media Technologies GmbH.

All other trademarks, product names, and company names mentioned in this document are the property of their respective owners.



Cymatic Technologies B.V. P.O. Box 208 6590 AE Gennep The Netherlands

www.cymaticaudio.com

Support:

support@cymaticaudio.com

© copyright 2016 Cymatic Technologies B.V.

User Manual uTrack-X32 Jan 2016